HAEKTPIKES ELECTRIC APPLIANCES

Models: DE-MDT10
DE-MDT20

User's Manual

osei simailaal

Αφυγραντήρας Εγχειρίδιο Χρήσης

English/Ελληνικά/ Română

Σας ευχαριστούμε που επιλέξατε αφυγραντήρα της INVENTOR. Για τη σωστή χρήση της μονάδας παρακαλούμε διαβάστε προσεκτικά το παρόν εγχειρίδιο και φυλάξτε το για αναφορά στο μέλλον.

Thank you for choosing INVENTOR dehumidifier. For correct use of this unit, please read this manual carefully and keep it for future reference.

inventor



inventor

Your-conditions

SOCIABLE REMARK

When using this dehumidifier in the European countries, the following information must be followed:

DISPOSAL: Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

It is prohibited to dispose of this appliance in domestic household waste. For disposal, there are several possibilities:

- A) The municipality has established collection systems, where electronic waste can be disposed of at least free of charge to the user.
- B) When buying a new product, the retailer will take back the old product at least free of charge.
- C) The manufacture will take back the old appliance for disposal at least free of charge to the user.
- D) As old products contain valuable resources, they can be sold to scrap metal dealers.

Wild disposal of waste in forests and landscapes endangers your health when hazardous substances leak into the ground-water and find their way into the food chain.



CONTENTS

SAFETY PRECAUTIONS	
Warning	. 2
Caution	. 2
Electrical information	. 3
CONTROL PADS ON THE DEHUMIDIFIER	
Indicator lights	. 4
Control pads	. 4
Other features	. 5
IDENTIFICATION OF PARTS	
Identification of parts	5
Identification of parts	. 6
OPERATIING THE UNIT	
When using the unit	_
When using the unit	. O
	. /
CARE AND MAINTENANCE	
Care and cleaning the dehumidifier	. 8
TROUBLESHOOTING TIPS	
Troubleshooting tips	9

Re ad Th is Ma nual

Inside you will find many helpful hints on how to use and maintain your air conditioner properly. Ju st a little preventive care on your part can save you agreat deal of time and money over the life of your air conditioner. You'll find many an swers to common problems in the chart of troubleshooting tips. If you review our chart of Troubles hooting Tips first, you may not need to call for service at all.



/!\ CA UTION

- T his appliance can be used by children a ged from 8 years and a bove and persons with reduced physical, se nsory or mental capabilities or lack of experience and k nowledge if they have been given supervision or instruction concerning use of the a ppliance in a safe way and understand the hazards involved. Children shall not play the appliance. Cleaning and user maintenances hall not be made by children without s upervision. (be applicable for the European Countries)
- T his appliance is not intended for use by persons (including children) with reduced p hysical, se nsory or mental capa bilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning us e of the appliance by a person responsible for their safety. (be a pplicable for other countries except the E uropean Countries)
- C hildren should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service a gent or similarly qualified persons in order to avoid a hazard.
- The appliance shall be installed in accordance with national wiring regulations.
- The appliance with electric heater shall have at least 1 meter space to the combustible
- C ontact the authorise diservice technician for repair or maintenance of this unit.



To prevent injury to the user or other people and property damage, the following instructions must be followed. Incorrect operation due to ignoring of instructions may cause harm or damage.

■ The seriousness is classified by the following indications.

\triangle	WARNING	This sym bol indicates the possibi lity of death or se rious injury.	
\triangle	CAUTION	This sym bol indicates the possibil ity of injury or d amage t o property.	

Meaning s of sym bols use d in this manual are as shown below.

\bigcirc	Never do this.
	Always do this.

▲ WARNING

- O Do not exceed the rating of the power outlet or connection device.
- Otherwise, it may cause electric shock or fire due to excess heat generation.
- ODo not modify power cord length or share the outlet with other appliances
- •It may cause electric shock or fire due to heat generation.
- O Disconnect the power if strange sounds, smell, or smoke comes from it.
- It may cause fire and electric shock.
- O Do not use the machine near flammable gas or combustibles, suc as gasoline, benzene, thinner, etc.
- •It may cause an explosion or fire.

- ODo not operate or stop the unit by switching on or off the power.
- It may cause electric shock or fire due to heat generation.
- ODo not insert or pull out plug with wet hands.
- It may cause electric shock.
- You should never try to take apart or repair the unit by vourself.
- It may cause failure of machine or electric shock
- ODo not drink or use the
- It contains contaminants and
- water drained from the unit.
- could make you sick.

- It may cause electric shock or fire.

O Do not damage or use an

unspecified power cord.

- O Do not place the unit near a heat source.
- Plastic parts may melt and cause
- 10 Before cleaning, turn off the power and unplug the
- It may cause electrical shock or injury.
- O Do not take the water bucket out during operation.
- It may cause bucket full protect of the unit and cause electric shock.

▲ CAUTION

- O Do not use the unit in small spaces.
- Lack of ventilation can cause overhe ating and fire.
- O Do not put in places where water may splash onto the
- Water may en ter the u nit and degrade the insulation. It may cause a n electric shock or fire.
- Place t he unit on a level, s turdy se ction of the floor.
- If the un it falls o ver, it may cause w ater to s pill and damage belongings, or cause e lectrical shock or fire.

▲ CAUTION

- O Do not cover the intake or exhaus t openings with cloths or towels.
- A lack of air flow can lead to overheating and fire.
- Never insert your finger or other foreign objects into grills or openings. Takes pecial care to warn children of these dangers.
- It may cause electric shock or failure of appliance.
- Always insert the filters securely. Clean filter once every two weeks.
- Opera tion without filters may c ause f ailure.


- Care sh ould be taken when using the unit in a room with the following persons:
- Infants, children, elderly people, and peo ple not s enstive to humidity.
- O Do not place heavy object on the power cord and take care so that the cord is not compress ed.
- There is danger of fire or electric shock.
- If water enters the unit, turn the unit off and disconnect the power, contact a qualified service technician.
- It may cause failure of appliance or accident.

- Do not use in areas where chemicals are handled.
- This will cause t he unit deterioration due to chemica Is and solvents dissolve d in the air.
- O Do not climb up on or sit on the unit.
- You may be injured if you fall or if the unit falls ove r.
- O Do not place flower vases or other water container on top of the unit.
- Water may spill in side the unit, causing insula tion failure and e lectrical shock or fire

Electrical Information

- The ma nufactures name plate is located on the rear pan el of the unit and contains electrical and other technical data specific to this unit.
- Be sure the unit is properly grounded. To minimize shock and fire hazards, proper grounding is important. The pow er cord is equip ped with a three -prong grounding plug for protection again st shock
- Your unit must be us ed in a p roperly grounded wall rec eptacle. If the wall recep tacle yo u intend to use i s not adequately grounded or protected by a time delay fuse or circ uit breaker, have a qualified electrician install the proper recepta cle.
- Ensure the receptacle is access ible after the unit installation.
- Do not use ext ension cords o ran ada pter plu gs with this un it. However, if it is nece ssary to use an extension cord, u se an ap proved "Dehum idifier" extension cord on ly (avail able at m ost loca I hardwa re
- To avoid the possib ility of personal injury, always disconnect the power supply to the unit, before in stalling and/or s ervicing.

The control panel of the dehumidifier you purch as ed may be look like one of the following:



Control panel(1)

Control panel(2)

In dic ator lights

- Power on indicator light(green)
- Bucket full indicator light(red)
- 3 Continuous operation on indicator light(green)
- Dis play

S hows the set % humidity level while setting, then s hows the actual(±5% accuracy) room % humidity level.

Error Codes:

- E 1- Humidity s ensor error--Unplug the unit and plug it back in. If error repeats, call for service.
- E 2- Temperature sensor error-- Unplug the unit and plug it back in. If error repeats, call for service. Protect Codes:
- P1- Unit is defrosting—Allow the unit to automatically defrost. The portect will clear after the unit's elf defrosts. P2- Bucket is full or bucket is not in the right position—Empty the bucket and replace in the right position.

Control pads

- POWER Pad Press to turn the dehumidifier on and off.
- Humidity S et Control Pads
 The humidity level can be s et within a
 range of 35%R H(R elative Humidity) to 80%

a higher percent value(%).

Continue Pad

S elect for the dehumidifier to operate continuously for maximum dehumidification until the bucket is full. The Humidity set control pads cannot be used when Continuous operation is on.P ress this pad again to cancel Continuous operation.

Otherfeatures

Bucket Full Light

Glows when the bucket is ready to be emptied, or when the bucket is removed or not replaced in the proper position.

Auto Shut Off

The water level control switch shuts off the dehumidifier when the bucket is full, or when the bucket is removed or not replaced in the proper position. When the setting humidity is reached, the unit will be shut off a utomatically.

Wait 3 minutes before resuming operation

After the unit has stopped, it can not be restart opertation in the first 3 minutes. This is to protect the unit. O peration will automatically startafter 3 minutes.

Auto Defrost

When frost builds up on the evaporator coils, the compressor will cycle off and the fan will continue to run until the frost disappears.

Auto-Restart(on some models)


If the unit breaks off unexpectedly due to the power cut, it will restart with the previous function setting automatically when the power resumes.


Identification of parts

- Control panel
- Air intake grille
- 3 Water bucket
- 4 Water level window
- 5 Handle
- **6** Air filter (behind the air intake grille)
- 7 Air Outlet grille
- 8 Drain hose outlet (see page 7)
- Power cord band (Used only when storing the unit.)
- Power Cord
- Power Plug

NOTE: All the pictures in the manual are for explanation purposes only. Your unit may be slightly different. The actual shape shall prevail. The operations and functions are the same.

6





Positioning the unit

A de humidifier operating in a base ment will have little or no effect in drying an a diacent enclose distorage a reaus uch as a closet, unless there is adequate circulation of air in and out of

- Do not use o utdoors.
- This dehumidifer is intended for indoor residential applications only. This dehumidifier should not be used for commercial or industrial applications.
- Place the dehumidifier on a smooth, level floor strong en ough to support the unit with a full bucket of water.
- Allow at least 20cm of airs pace on all sides of the unit for good air circulation.
- Place the unit in an area where the temperature will not fall below 5°C(41°F). The coils can become covered with frost at temperatures below 5°C(41°F), which may reduce performance.
- Place the unit away from the clothes dryer, heater or radiator.
- Use the unit to prevent moisture damage a nywhere books or valuables a re stored.
- Use the dehumidifier in a base ment to help prevent moisture damage.
- The dehumidifier must be operated in an enclose d area to be most effective.
- Close all doors, windows and other outside openings to the room.




Fig.4

Casters(Install at four points on the bottom

- Casters can only move laterally.
- •Do not force casters to move over carpet, nor move the unit with water in the bucket. (The unit may tip over and spill water.)

NOTE:Casters is optional, some models without.

When using the unit

- When first using the dehumidifier, operate the unit continuously 24 hours.
- This unit is designed to operate with a working environment between 5°C(41°F) and 35°C(95°F).
- If the unit has been switched off and needs to be switched on again quickly, a llow approximately three minutes for the correct operation to resume.
- Do not connect the dehumidifier to a multiple socket outlet, which is a lso being us ed for other electrical appliances.
- Se lect a suitable location, making sure you have easy access to an electrical outlet.
- Plug the unit into a 115V~ 60Hz/220~240V 50Hz (Re fer to the nameplate located on the side/rear of the unit) electrical so cket-outlet with earth connection.
- Make sure the Water bucket is correctly fitted otherwise the unit will not operate properly.

Removing the collected water

There are two ways to remove collected water.

- 1. Use the bucket
- When the bucket is full, the unit will automatically stop running, and the Full indicator light will flash.
- Slowly pull out the bucket. Grip the left and right handles securely, and carefully pull out straight so water does not spill. Do not put the bucket on the floor because the bottom of the bucket is uneven. Otherwise the bucket will fall and cause the water to spill.
- Throw away the water and replace the bucket. The bucket must be in place and securely seated for the dehumidifier to operate.
- The machine will re-start when the bucket is restored in its correct position.

- When you remove the bucket, do not touch any parts inside of the unit. Doing so may damage the product.
- Be sure to push the bucket gently all the way into the unit. Banging the bucket against anything or failing to push it in securely may cause the unit not to operate.

2. Continuous draining

Water can be automatically emptied into a floor drain by attaching the unit with a water hose (ID \$\Phi 3.5mm) (not included).

- Re move the rubber plug from the back of the unit and store it in a sa fe location.
- Insert the water hose into the unit from the drain outlet in the back of the unit as shown in Fig.8. Make sure the connection of the water hose and the drain hose outlet of the unit is tight and do not let the water leak.
- Then lead the water hose to the floor drain or a suitable drainage facility. The drainage facility should be lower than the drain outlet
- Be sure to run the water hose s loping downward and let the water to flow out smoothly. Do not install the water hose a s shown Fig.9a and Fig.9b.

NOTE: When the continuous drain feature is not being used remove the drain hose from the outlet and attach the rubber plug back to the drain outlet.



Do not block water flow by a rise.

1. Pull out the bucket a little.




2. Hold both sides of the bucket with even strength, and pull it out from the unit.



3. Pour the water out.



Fig.7





Do not block water flow by a retortion.

Care and cleaning of the dehumidifier

Turn the dehumidifier off and remove the plug from the wall outlet before cleaning.

- 1. Clean the Grille and Case
- Use water and a mild detergent. Do not use bleach or abrasives.
- Do not splash water directly onto the main unit. Doing so may cause an electrical shock, cause the insulation to deteriorate, or cause the unit to rust.
- The air intake and outlet grilles get soiled easily, so use a vacuum attachment or brush to clean.

2. Clean the bucket

Every few weeks, clean the bucket to prevent growth of mold, mildew and bacteria. Partially fill the bucket with clean water and add a little mild detergent. Swish it around in the bucket, empty and rinse.

NOTE: Do not use a dishwasher to clean the bucket. After clean, the bucket must be in place and securely seated for the dehumidifier to operate.

3. Clean the air filter

The air filter behind the front grille should be checked and cleaned at least every 30 days or more often if necessary. NOTE: DO NOT RINSE OR PUT THE FILTER IN AN AUTOMATIC DISHWASHER.

To remove:

- Pull the water bucket out as shown in Fig.9.
- Grasp the lower side of the filter and pull it downward, see Fig.10.

Clean the filter with warm, soapy water. Rinse and let the filter dry before replacing it. Do not clean the filter in a dishwasher.


To attach:

Insert the air filter into the unit from the side and push it upward. See Fig.10.

• CAUTION:

DO NOT operate the dehumidifier without a filter because dirt and lint will clog it and reduce performance.

- 4. When not using the unit for long time periods
- After turning off the unit, wait one day before emptying the tank.
- Clean the main unit, bucket and air filter.
- Wrap the cord and bundle it with the band(see Fig.12).
- Cover the unit with a plastic bag.
- Store the unit upright in a dry, well-ventilated place.







Fig.12

Before calling for service, review the chart below first yourself.

Problem What to check • Make sure the dehumidifier s'plug is pushed completely into the 1111111 Unit does not start • Check the house fuse/circuit breaker box. • Dehumidifier has reached its preset level or bucket is full. • Bucket is not in the proper position. Did not allow enough time to remove the moisture. • Make sure there are no curtains, blinds or furniture blocking the front or back of the dehumidifier. • The humidity selector may not be set low enough. Dehumidifier does not • Check that all doors, windows and other openings are securely dry the air as it should • Room temperature is too low, below 5°C(41°F). • There is a kerosene heater or something giving off water vapor • The air filter is cloqued. The unit makes a loud • The unit is tilted instead of upright as it should be. noise when operating The floor surface is not level.





• This is normal. The unit has Auto defrost feature.



• Hose to connector or hose connection may be loose. • Intend to use the bucket to collect water, but the back

drain plug is removed.

Power indicator light flashes at 5 times per second.



• Temperature sensor or Humidity sensor error. Unplug the unit and plug it back in. If error repeats, call for service.



